EL-DataPad





The EL-DataPad allows users of certain EL-USB data loggers to configure their units, upload data, and view logging results on-the-spot rather than moving the logger to their PC. This allows shorter breaks in data collection for more data continuity, less travel time, and on-the-spot data review and data logger reconfiguration.

The logger is connected to the EL-DataPad via a standard USB port at the top of the DataPad. Once connected, you are guided through a simple touchscreen menu with options to Set-Up Logger, Stop Logger & Download and View Data. On-screen instructions follow the same structure as EL-USB-WIN software for the PC currently provided with each data logger.

Data from up to 100 loggers can be viewed on the EL-DataPad, with data from a further 400 units stored on the unit at any one time. Data can be transferred to a PC using a supplied micro USB cable. Once uploaded, data is saved in comma separated variable (csv) format, making it suitable for import into spreadsheet programs such as Microsoft Excel or graphed on a PC using EL-WIN-USB software.

Features

- Archive capacity for up to 500 logger uploads
- View uploaded data with general trend and summary reports
- · Allows full or quick set-up of compatible EL-USB data loggers
- Touch screen interface for navigation of menus
- 2.8 inch full color TFT display
- Stored data can be transferred to a PC via micro USB cable
- Rechargeable internal built-in lithium battery provides up to 8 hours of use between charges

Compatible EL-USB Data Loggers

The EL-DataPad is compatible with the following Data Loggers:

- EL-USB-1
- EL-USB-1-LCD
- EL-USB-1-PRO
- EL-USB-2
- EL-USB-2+
- EL-USB-2-LCD
- EL-USB-2-LCD+
- EL-USB-TC
- EL-USB-TC-LCD

Controls and Setup



Download and view data directly from data logger.





Upload Data to a PC for further analysis

EL-DataPad Typical Setup and Operation

1. Configure your EL-USB data logger using the EL-DataPad. On the home screen choose "**Set-Up Logger**."





2. Your options are "Full Set-Up" or "Quick Set-Up." Choose "Quick-Set-Up" if you've already configured your EL-USB data logger and simply wish to begin recording a new file. Choose "Full Set-Up" to configure your data logger.

3. Press "Change Name" and give your EL-USB data logger a unique name to distinguish it from other EL-USB data loggers.



EL-DataPad Typical Setup and Operation (continued)





4. Set the scale (in this case °C or °F) and the sample frequency.

5. You can also set temperature and humidity alarms.







6. Enter precise alarm values with the numbered touchpad.

EL-DataPad Typical Setup and Operation (continued)

7. Select "Immediate Start" to begin recording immediately or select "Delay Start" to schedule a start date and time.







8. Remove your data logger from the EL-DataPad and start recording data.

9. Plug your EL-USB data logger back into the EL-DataPad to archive and view recorded data.



Dimensions



Dimensions shown are inches (mm)

Specifications

| Specification | Minimum | Typical | Maximum | Unit | |
|-----------------------------------|---------|---------|-----------|------------------|--|
| Data recording capacity | | >8.5 | | million readings | |
| Operating time (on single charge) | | 8* | | hours | |
| Operating Temperature Range | 0 (32) | | +50 (122) | °C (°F) | |

^{*5} hours constant use

| Specification | Description | | | | | | |
|---------------|--|--|--|--|--|--|--|
| Compatibility | PC (XP, Vista, Win 7) | | | | | | |
| Battery | Lithium Polymer, rechargeable via micro-USB connection. | | | | | | |
| LCD | 240x320 2.8" TFT with touch-screen. | | | | | | |
| Memory | Internal flash. | | | | | | |
| Controls | Single front-panel push-button used for power-switch. Single press=ON, press and hold for 3 sec = OFF | | | | | | |
| Connections | 1x USB Type A socket (top of unit) for connection of data loggers. 1x micro-USB (bottom of unit) for connection of unit to PC via 1m USB cable supplied. | | | | | | |

EL-DataPad Ordering Information

| Description | Order Number | | |
|--|--------------|--|--|
| EL-DataPad Includes EL-DataPad, micro USB cable, software on CD, and Quick Start Guide. | EL-DataPad | | |

EL-USB Data Logger Series Overview

EasyLog Products for Any Application

From temperature and humidity to carbon monoxide trending, there's an EasyLog data logger that's right for you. Click on "Jump" to go to the product's web page.

| Mea | surement | Model EL-USB- | | | | | | | | | | | | | |
|--|---|---------------|-------|------------|-------------|------|------|-------------|-------------|------|------|-------------|------|-------------|-------------|
| Function | Range | 1 | 1-LCD | 1- RCG* | 1-PRO | 2 | 2+ | 2-LCD | 2- LCD+ | 3* | 4* | 5* | тс | TC- LCD | CO* |
| Temperature | -35 to +80°C (-31 to +176°F) | Jump | Jump | | | | | | | | | | | | |
| Temperature | -20 to +60°C (-4 to +140°F) | | | Jump | | | | | | | | | | | |
| High Temperature | -40 to +125°C (-40 to +257°F) | | | | <u>Jump</u> | | | | | | | | | | |
| Humidity, temperature, dew point | 0 to 100% RH -35 to +80°C (-31 to +176°F) | | | | | Jump | Jump | <u>Jump</u> | <u>Jump</u> | | | | | | |
| Voltage | 0 to 30 VDC | | | | | | | | | Jump | | | | | |
| Process current | 4 to 20 mA | | | | | | | | | | Jump | | | | |
| Event, State, Count | 3-28 VDC | | | | | | | | | | | <u>Jump</u> | | | |
| Thermocouple (no display) | -130 to +900°C (J) -200 to +1300°C (K) -200 to +350°C (T) | | | | | | | | | | | | Jump | | |
| Thermocouple (with display) | -130 to +900°C (J) -200 to +1300°C (K) -200 to +350°C (T) | | | | | | | | | | | | | <u>Jump</u> | |
| Carbon monoxide | 0 to 1000 ppm | | | | | | | | | | | | | | <u>Jump</u> |

^{*} Please Note: These products are NOT compatible with the EL-DataPad.



DATAQ Instruments, Inc. 241 Springside Drive Akron, Ohio 44333 Phone: 330-668-1444

Fax: 330-666-5434

Supplied in Australia by Instrument Choice Call our scientists on 1300 737 871 www.instrumentchoice.com.au

Data Acquisition Product Links

(click on text to jump to page)

Data Acquisition | Data Logger | Chart Recorder