

Logger HeatLOG




Measure the product core temperature in all your processes

°C
°F

Compatible enclosure heated by water, steam and microwave

Strong miniaturization and fast response time

High precision temperature data logger



Logger HeatLOG



Measure the product core temperature in all your processes

Specificities

- Meets direct food** contact standards
- Compatible** with conventional thermal or microwave processes
- Usable in any** type of packaging
- Fully** maintenance free
- 2 to 5 years lifetime** upon the frequency of use

Applications

- Pasteurization and sterilization** of food products
- Accurate PU / F0** in all packaging over 80 g
- Control** of microwave pasteurization tunnels
- Optimization** of thermal process construction
- Works with **AXITHERM** communication interfaces and softwares

Performances

- Environment** temperature measurement without disturbance
- Weight** of 6,1 g for a volume of 1.92 cm³
- 3 temperature ranges** to meet all your requirements:
-40 to +85°C / 0 to +125 °C / +15 to +140 °C
- High miniaturization** Ø 16.4 x 9,1 mm
- Accuracy better** than ± 0.15 ° C
- Wartertightness:** IP 68 from -1 to +3 bar
- Memory capacity:** 4096 données
- 3 recording modes:** immediate - date/time - temperature thresholds
- Insensitive** to microwaves (acquisition speed = every 15s or more)



AXITHERM SARL

35 FONTEVRAULT STREET - 72200 LA FLÈCHE - FRANCE

Phone : +33 243 960 378

Email : contact@axitherm.com - www.axitherm.com

capital of 15245€, RCS of LE MANS 44100455300026 – code APE 8299 Z

N° VAT FR 19 441 004 553

