



MT26 Bluetooth Compact Multimeter

The MT26 is a CAT III 600V True RMS compact multimeter offering measurements of AC and DC voltage, AC and DC current, frequency, capacitance, resistance and temperature. The meter has a large 4000 count backlit LCD with the added advantage of an analogue bar graph. The Low Z function has a low pass filter to eliminate errors caused by "Ghost" voltages. There is a built-in LED flashlight for dimly lit areas and a tilt stand. The Bluetooth function allows the user to transmit data to the Android or iOS mobile App for viewing, organising and sharing recordings. The meter has a double moulded rubber case with IP67 waterproof and dustproof rating.



Features

- 4000 count with 41 Segment Barograph
- Measures AC and DC voltage up to 600V
- Temperature measurement from -18°C to 760°C
- Capacitance to 4000 μ F
- Frequency to 10MHz
- Duty Cycle
- Min, Max and Data Hold
- Auto Power Off
- LED Flashlight
- IP67 Dust & Waterproof

Function	Range	Accuracy
DC Voltage	400.0mV – 600V	$\pm(1.0\% +3)$
DC Voltage LowZ	400.0mV – 400V	$\pm(1.5\% +3)$
AC Voltage	4.000V – 600V	$\pm(1.2\% +5)$
AC Voltage LowZ	4.000V – 400V	$\pm(1.5\% +5)$
DC Current	4.000A – 10A	$\pm(2.0\% +3)$
AC Current	4.000A – 10A	$\pm(2.5\% +3)$
Resistance	400.0 Ω – 40M Ω	$\pm(1.5\% +5)$
Frequency	9.999Hz – 9.999MHz	$\pm(1.0\% +5)$
Capacitance	40.00nF – 4000 μ F	$\pm(3.0\% +5)$
Temperature	18°C – 760°C	$\pm(2.0\% +5^{\circ}\text{C})$
Duty Cycle	0.1% to 99.9%	$\pm(1.2\% +2)$
Size	147 x 68 x 50mm	
Weight	318gm	



4000 Count Backlit LCD Display



IP67 Dust & Waterproof Double Moulded Housing



Tilt Stand & Flashlight

MT26 | 600V AC/DC Multimeter

Contact Us
South Africa

www.major-tech.com sales@major-tech.com

Australia

www.major-tech.com.au info@major-tech.com.au