




The **@WEIGH** series of digital Hanging Scales, offers the user a simple and easy method to weigh goods in a lifting / tension application, from 30kg to 300kg capacities.

Comes standard with top stainless steel shackle and stainless steel bottom hook.

Standard 20mm LCD display up to 150 hours of continuous operation makes for easy reading of the displayed weight. With standard Zero, Tare In / Tare Out function, Stable function makes this a very simple to use scale. Or as a replacement of older mechanical dial scales.

The @WEIGH hanging scale is also able to read weights in **kg**, **lb** & **N** as well as converting these from one weigh reading to other while in use. Some other handy features include an overload alarm to warn you if have gone over the capacity of the scale plus a battery indication function to warn you of the current battery power level.

The applications are limitless from Food industry Fishing Industry, Measuring Tension Forces and General Tension weighing at low capacities. (Non trade weighing applications only)





Telephone 1300 SCALES • facsimile 1300 2WEIGH • sales@weigh.com.au (722 537) (293 444)



🖌 Die Cast Aluminium enclosure	3 x AA Battery power supply
🐓 20mm LCD Display	Waterproof front panel buttons
4 Stainless Steel Top Shackle	Simple 3 button operation
Stainless Steel Bottom Hook	Capacities from 30kg to 300kg
Choice of four colours depending on	Lightweight at only 620 grams
capacity	

Model	Capacity	LCD Display
CR-30:	30kg x 0.01kg	5 digits @ 20mm
CR-100	100g x 0.05kg	5 digits @ 20mm
CR -200	200kg x 0.1kg	5 digits @ 20mm
CR-300	300kg x 0.1kg	5 digits @ 20mm

Safe Overload Capacity:	120% F.S
Overload Alarm	100% FS + 9e
Safe Overload Capacity:	120% F.S
Ultimate Overload Capacity	300% F.S
Zero Range	4% F.S
Tare Range:	100% F.S
Finish:	Cast Aluminium casing.
Operating Temperatures:	-10 degrees C to 40 degrees C
Operating Humidity:	<85% RH under 20 degrees C
Display reading:	Kg, Lb & N
Battery life @ new	LCD = 150 hours continuous working with new batteries.
Auto Shut Off:	Yes.
Net Weight:	620 grams
Shipping Weight:	1.0kg
CAUTION:	Overloading of hanging scale will void all warranty claims and can result in serious injury or death