

AGRETO Hour meter AgriCounter Vibration

Applications:

- Electronic hour meter for all types of machines and devices
- Ideal for community and rental machines

Technical details:

- Activation by motion/vibration of the machine
- Separate summation of working time (use in the field) and travel time (travel to the field) possible by changing the position of the counter
- Hour display optionally in h:mm or h, hh
- Possibility of setting the necessary intensity of movement for activating the counting process
- Large, permanently switched on LCD display
- Six-digit display with digits 11 mm high
- Symbols for displaying additional information
- Robust, one-piece plastic housing
- Protection class IP69k (pressure washer-resistant)
- Tamper-proof by lead sealing of the housing screws - Zeroing, adjustment of settings and change of battery only possible by visible damage to the lead seal
- Powered by 2 included AAA batteries
- Battery life approx. 3 years
- Dimensions: 93 x 52 x 33 mm (W x D x H)
- Package includes: Counter, 5 lead seals, manual
- State-of-the-art technology Made in Austria
- 5 year warranty

Benefits:

- Simple, reliable operating hour meter
- Exact time recording with 3-axis sensor
- Determine operating time and travel time separately
- Fair billing base according to real use
- Optimisation of service intervals for operating time
- No manipulation possible by the user

