



® Knowledge Beyond Measure.

# DP-Calc™ Micromanometers

Models 5815 and 5825



**The DP-Calc™ 5815 and 5825 micromanometers allow you to easily make HVAC pressure measurements. These robust instruments can be used with Pitot probes to measure duct velocity.**

The DP-Calc™ 5815 is a simple to operate, hand held digital micromanometer for fast, accurate differential and static pressure measurements. The high performance DP-Calc 5825 can calculate flow and has data logging capabilities.

## Applications

- HVAC commissioning and troubleshooting
- Testing and balancing
- Pitot tube duct traverses
- Static pressure measurements
- Pressure drop across filters, coils, fans, and diffusers
- Environmental air flow testing

## Features and Benefits

- Measure differential and static pressure from -15 to +15 in. H<sub>2</sub>O (-3735 to +3735 Pa)
- Calculate and display velocity when using a Pitot tube

## Added Features Model 5825

- Calculates flow
- Variable time constant
- Statistics
- Data logging with time and date stamp
- Stores 12,700+ samples and 100 test IDs
- Programmable K factors



## Specifications

# DP-Calc™ Micromanometers

Models 5815 and 5825

### Static/Differential Pressure

Range<sup>1</sup> -15 to +15 in. H<sub>2</sub>O  
(-28.0 to +28.0 mm Hg, -3735 to +3735 Pa)

Accuracy ±1% of reading ±0.005 in. H<sub>2</sub>O  
(±0.01 mm Hg, ±1 Pa)

Resolution 0.001 in. H<sub>2</sub>O (0.1 Pa, 0.01 mm Hg)

### Velocity (Pitot Tube)

Range<sup>2</sup> 250 to 15,500 ft/min (1.27 to 78.7 m/s)

Accuracy<sup>3</sup> ±1.5% at 2,000 ft/min (10.16 m/s)

Resolution 1 ft/min (0.1 m/s)

### Duct Size (5825)

1 to 500 inches in increments of 0.1 in.

(2.5 to 1270 cm in increments of 0.1 cm)

### Volumetric Flow Rate (5825)

Range Actual range is a function of velocity,  
pressure, duct size, and K factor

### Instrument Temperature Range

Operating 40 to 113°F (5 to 45°C)

Storage -4 to 140°F (-20 to 60°C)

<sup>1</sup>Overpressure range = 190 in. H<sub>2</sub>O (7 psi, 360 mmHg, 48 kPa).

<sup>2</sup>Pressure velocity measurements are not recommended below  
1,000 ft/min (5 m/s).

<sup>3</sup>Accuracy is a function of converting pressure to velocity.  
Conversion accuracy improves when actual pressure  
values increase.

Specifications are subject to change without notice.

TSI, and the TSI logo are trademarks are registered trademarks of  
TSI Incorporated in the United States and may be protected under  
other country's trademark registrations.

### Data Storage Capabilities (5825)

Range 12,700+ samples and 100 test IDs

### Logging Interval (5825)

1 second to 1 hour

### Time Constant (5825)

User selectable

### External Meter Dimensions

3.3 in. x 7.0 in. x 1.8 in. (8.4 cm x 17.8 cm x 4.4 cm)

### Meter Weight with Batteries

0.6 lbs. (0.27 kg)

### Power Requirements

Four AA-size batteries (5815)

Four AA-size batteries or optional AC adapter (5825)

	Model 5815	Model 5825
Differential and static pressure	▪	▪
Velocity with pitot tube	▪	▪
Sample statistics		▪
Volumetric flow rate		▪
Actual and standard velocity		▪
Variable time constant		▪
K factor		▪
Certificate of Calibration	▪	▪



Knowledge Beyond Measure.

TSI Incorporated - Visit our website [www.tsi.com](http://www.tsi.com) for more information.

USA Tel: +1 800 874 2811  
UK Tel: +44 149 4 459200  
France Tel: +33 1 41 19 21 99  
Germany Tel: +49 241 523030

India Tel: +91 80 67877200  
China Tel: +86 10 8219 7688  
Singapore Tel: +65 6595 6388