## **VersaLog**

## Model: TC





4-mega byte memory stores up to 2 million measurements

One on-board thermistor channel monitors ambient temperature

Seven range programmable thermocouple voltage input channels cover wide measurement requirements

Accepts thermocouple types E, N, J, K and T  $\,$ 

Can be accessed via USB, MODEM, or Ethernet connections with auto baud rate of up to 115 kbps

10-year battery life

Fast sampling mode

Alarm and excitation output







The VersaLog TC is an 8-channel, battery powered, stand-alone thermocouple data logger. It records the ambient temperature and the seven external thermocouple probes. Data is stored in non-volatile flash memory for later retrieval.

VersaLog TC can also be used as a small voltage data logger with the input voltage range as small as -2 mV to +12 mV.

Featuring an aluminum enclosure the VersaLog logger has excellent performance in the harshest industrial environment.

Powered by a 16-bit ADC and programmable input range, the VersaLog logger is well suited to science and laboratory applications where precise and accurate measurement is critical.

## **SiteView Software**

SiteView is a Windows-based application which works with the VersaLog Series data loggers for downloading, configuration, data analyzing and plotting. Its user-friendly graphic interface plus powerful functionalities fit both novice and advanced users.

The versatility of custom equation and custom-line equation handles complicated measurement requirements.

- Supports USB, Serial port and Ethernet connections for easy local and remote access
- Fast communication speed up to 115200 bps makes downloading fast

- · Real-time viewing and chart recording replaces chart recording devices
- · Custom equation and custom-line equation solves scientific and laboratory algorithm difficulties
- · Zoom in/zoom out, annotation/label of graph functions provide detailed view of data
- Multiple file loading allows easy data comparison
- · Dynamic statistics provide detailed information of current zoomed view

## Technical specifications (subject to change without notice)

Inputs	
Channels	On-board thermistor reference temperature ( -40°F $\sim$ 158°F), Seven external thermocouple inputs with programmable ranges
Туре	E, N, J, K, T
Accuracy	Reference Temperature: 0.36°F Thermocouple Inputs: +/- 0.2% + T/C Accuracy @ 25°C
Over-voltage protection	+/- 40 VDC
Alarms	
Channel Alarms	Two editable alarm thresholds per channel
Alarm Outputs	ALARM1 & A2/EXT terminal strips can be configured as alarm outputs
	Alarm-On: MOSFET (N-Channel) switch on Alarm-Off: MOSFET (N-Channel) switch off
	Max Power: 200mA @ 24VDC
	Can report alarm status to host PC via USB, Modem or Ethernet Device Server with SiteView software <sup>[2]</sup>
Alarm-On Delay	Programmable 0 - 10 minutes delay with 1-minute increments
Alarm Indicator	On-board LED lights in red when in alarm condition
On-Board Memory	
Capacity	4MB ~ 2 million measurements
Data Retention	Over 20 years
Sampling & Logging	
Sampling Interval	20 milliseconds <sup>[1]</sup> to 12 hours user selectable
Logging Mode	Stop recording or FIFO when memory is full
Logging Activation	Programmable instant, start delay or field push-button activation

Communicat	tions
Interface	USB (USB cable included), AUX (RJ11) for direct TTL level communications
	Can be connected to Ethernet for remote access with DeviceServer Kit $^{\!$
Baud Rate	Auto-detect baud rate from 2400 to 115200 bps on both USB and AUX ports
Battery	
Power	Built-in 3.6V Lithium Battery
Life Cycle	10 years based on 1 minute sampling interval
Software	
SiteView <sup>[2]</sup>	Configuration, downloading, plotting, real-time view, custom calibration and custom equation
Software Requirements	Computer with 1.0 GHz or faster processor, 256 MB Memory or higher & 1.0 GB of available hard-drive space or higher
	Windows XP with SP2 or later, Vista, Windows 7, 8
	At least one USB port or one COM port
Other	
LED Indicator	Normal Sampling: green when sampling Alarm: red when sampling Low Battery: amber when sampling
<b>Excitation Control</b>	A2/EXT terminal strip can be configured as excitation control output for powering connected devices
	Warm-up delay Interval settings: 10 to 240 seconds with 10-second increments
Operating Environment	-40 ~ +70°C (-40°F ~ 158°F), 0~95%RH non-condensing
Clock Accuracy	+/- 1 minute per month
Approvals	CE, FCC

[1]: Maximum enabled channel: 1 for 20ms interval, 2 for 30ms, 8 for 40ms or bigger interval.

[2]: Sold separately.